

mélisande

[ÉLECTROTRAD]

TECH RIDER

Contact :

Alexandre de Grosbois-Garand

1-514-823-1872

productionsdumoulin@gmail.com

In and sound check : 2 hours Out: 1 hour

The system must be installed and functional when artists arrive

BACK LINE :

- 3 keyboard stands (single)
- 1 good quality drum kit with a rug
- 1 drum stool for violin player
- 1 riser 8 feet x 8 feet for the drum

TECHNICAL NEEDS :

- amplification : minimum 10 watts per seat (ex : 1000 watts for 100 seats)
- * 1 board 32 IN mic (if not digital, with an EQ, FX and comp. rack)
- ideally the board must be placed in the center of the room (not on the side of the wall nor on a mezzanine)
- ~~One Cat5 network cable from stage to FOH booth~~
- complete set of microphones for drum
- electricity on stage for all musicians except singer
- ~~2 SIDE FILLS monitors~~

WE PROVIDE

- Midas M32c mixing board (rack) on-stage
- Midas DL32 stagebox
- Wireless router for local network
- IEM systems for every musicians
- D.I. boxes for every instruments
- 3 vocal mics + every instrument mics (except for drums)
- XLR cables for every instruments and mics

* Unless it is impossible, our sound engineer will mix the FOH using our on-stage M32c mixing board via laptop and/or iPad

PATCH	INSTRUMENT	SOURCE		NOTE
1	KICK IN	Beta 52a	No stand	
2	SNARE	SM57	Short boom	
3	HH	KM-184	Short boom	48v
4	RACK	e604		
5	FLOOR	e604		
6	OH	KM-184	Tall boom	48v
7	DRUM PAD KICK	Stereo JDI - provided		
8	DRUM PAD RYTHM	Stereo JDI - provided		
9	PLAYBACK L	Pro D8 - provided		
10	PLAYBACK R	Pro D8 - provided		
11	KEYS L	Pro D8 - provided		
12	KEYS R	Pro D8 - provided		
13	BASS PLAYBACK	Pro D8 - provided		
14	ELECTRIC BASS	RADIAL J48 - provided		48v
15	FLUTE	DPA 4099 Wireless - provided		
16	MININOVA KEYS	Digiflex DPDI - provided		
17	FOOT PERCUSSION	XLR		48v
18	BANJO	XLR	preamp	
19	VIOLIN MIC	XLR		48v
20	VIOLIN PICKUP	XLR	preamp	
21	VOX VIOLIN	e935 - provided	Tall boom	
22	VOX LEAD	WIRELESS e935 - provided	Tall boom	
23	VOX KEYS	e935 - provided	Tall boom	
24	BULLET MIC	Digiflex DPDI - provided	Overdrive pedal	

OUTPUT	MIX		
1	DRUM IEM L	XLR	
2	DRUM IEM R	XLR	
3	VIOLIN IEM L	XLR	
4	VIOLIN IEM R	XLR	
5	LEAD SINGER IEM L	WIRELESS	
6	LEAD SINGER IEM R	WIRELESS	
7	KEYS IEM L	WIRELESS	
8	KEYS IEM R	WIRELESS	
9	SIDE FILL SR	SPEAKER ON STAND	
10	SIDE FILL SL	SPEAKER ON STAND	

FOOT PERC : XLR
VIOLIN PICKUP : XLR
VIOLIN MIC : XLR
BANJO : XLR

MIX 3

DRUM PAD : STEREO
DI

STEREO IEM XLR
MIXES 1-2

PLAYBACK : STEREO
DI
KEYS : STEREO DI
BASS : XLR
FLUTE : XLR



MIX 5

DANCE AREA

WIRELESS VOCAL
MIC

DANCE AREA

SIDE FILL SR
MIX 6

MIX 4

SIDE FILL SL
MIX 7

